

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
1	185656	Left Cover	41	185644	Screw
2	181724	Flat Washer	42	185645	Wind Guide block B
3	185652	Belt	43	185658	Bearing
4	185619	Screw	44	185659	Cutter Body
5	185655	Passive wheel	45	181771	Adjust bracket
6	185654	Big plate	46	185664	Spring
7	185678	Bearing	47	185665	Adjusting Plate A
8	181743	Tapping screw	48	185669	Steel ball
9	185651	Driving Wheel	49	185670	Spring
10	185650	Small plate	50	185661	Adjusting knob
11	185649	Bearing	51	185666	Spring
12	185624	Right Housing	52	185668	Bolt
13	185632	Slot	53	185662	Graduation Ring
14	185679	Screw	54	185663	Nut Bushing
15	185630	Base plate	55	185667	Adjusting Plate B
16	185633	Air Deflector	56	185625	Right Cover
17	185631	Support	57	181753	Brush Lining
18	181748	Cable	58	181723	Screw
19	181756	Tapping screw	59	185660	Knob Cover
20	185620	Cable Clamp	60	185647	Spanner
21	185618	Cable bushing	61	185648	Wrench box
22	181781	Capacitance	62	185621	Ne light
23	185622	Light cover	63	185677	Dust bag
25	181736	Switch	64	185675	Dust extraction Adaptor
26	185623	Hand cover	65	185673	Bolt
27	185627	Adjustable flap	66	181774	Bolt
28	185634	Bearing	67	185680	Wire ties
29	181751	Brush Holder	68	185674	Fixed fram
30	185642	Rotator	69	185671	Bolt
31	185643	Stator	70	181783	Screw
32	185628	Push block	71	181782	Bushing
33	185629	Spring	72	185672	Depth gauge
34	181769	Flat Washer	73	181775	Wing nut
35	185635	Baffle	74	181777	Cutting Width Guide
36	185637	Screw	75	185676	Steel wire
37	185636	Bushing	76	181784	Knob
38	185638	Spring	77	185640	Screw
39	185639	Support	78	185646	Left Housing
40	185641	Wind Guide block A			

P 282N

