

M 902 - 127638; M 902A - 127638

POS. No.	Ref.No.	Description
1*	122936	Body
1**	127633	Body
2	122938	Diffuser
3	124128	Stator set
4	112240	Armature set
5	330287	Bearing 627-2ZP6LDS18
6	100429	Fan
7	360646	Screw 4x9.5
8	121263	Brush holder cover
9	120964	Brush with a switch
10	120965	Brush
11	112242	Brush holder set
12	164934	Rubber bush
13	127544	Capacitor
14	112278	Spring
15	120503	Gear box set
16	330287	Bearing 627-2ZP6LDS18
17*	112235	Bearing bed
18	113091	Spacer washer
19	112218	Spindle
20	330117	Bearing 6202-2RS
21	330330	O-ring 31X2B
22	330732	Circlip A35-1D
23	112913	Spacer washer
24	112914	Spacer washer
25	112915	Spacer washer
26	114226	Gear set
27	115162	Bush
28	330334	O-ring 22X2B
29	115721	Washer
30	330291	Bearing 60002ZP63LDS18

POS. No.	Ref.No.	Description
31	330471	Circlip A26-1
33	330379	O-ring 66X2B
34	360409	Screw M 5X12 8.8
35	121264	Lock button
36	115165	Spring
37	330335	O-ring 16X2B
38	121262	Casing handle set
39	111874	Switch KD10
40	256500	Cord clamp
41	360646	Screw 4x9.5
42	360654	Screw 4x18
43	360318	Screw A-K 5x25
44	117246	Cord with a plug
45	206687	Cord protector
46	121837	Back up disc washer
47	121838	Locking nut
48	154268	Spanner 173 set
[1]	49*	113479 Guard 150
[2]	49*	115193 Guard
	50	121265 Handle
100**	120505	Bearing bed
[1]	101**	151733 Guard 150
[2]	101**	151194 Disk guard 125

Note: \*-fill 01.01.2001; \*\*-from 01.01.2001  
 [1] - only for M 902; [2] - only for M 902A

M 902  
M 902A

