

M 2000/AVR - 174030; M 2000 - 174030; MA 2000/AVR - 174031; MA 2000 - 174031

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description	
1	174013	Gear box	32	164934	Rubber bush	
2	330125	Bearing HK 1212	33	360646	Screw 4x9,5	
3	330944	Bearing 6300.2RSL.P63.LDS18SpA	34	152537	Screw 3,9X74	
4	153341	Gasket	35	154350	Fan	
5	173936	Inner Flange	36	151648	Protective washer	
6	173934	Circlip	37	331149	Bearing 608-2RS-P63.LDS18SpA	
7	174022	Spindle	38	174002	Handle	
8	173935	Rubber bush	39	170660	Switch PS 16 E00	
9	174012	Bearing bed	40	360654	Screw 4x18	
10	117504	Spacer washer	41	151671	Cord clamp	
11	117505	Spacer washer	42	360646	Screw 4x9,5	
[1][2]	152668	Gear set	43	361120	Screw K5X40(D10)	
[3][4]	152666	Gear set	44	120724	Cord protector	
13	113256	Nut	45	152574	Cord with a plug	
14	174007	Bush	46	360255	Screw A-K 5x30	
15	174021	Spring	47	121837	Back up disc washer	
16	174008	Pin	48	121838	Locking nut	
17	330344	O-ring 6X1.5B.NBR70	[1][2]	49	151276	Disk guard 180E
18	330352	O-ring 80X2B	[3][4]	49	151268	Disk guard 230E
19	360246	Screw M5x16	50	154269	Special spanner 240	
20	174006	Button	[1][3]	51	173725	Handle AVR M14/L12
21	174020	Protective washer	[2][4]	51	121265	Handle
22	330473	Circlip A40-1D	52	113244	Spiral spring	
23	330124	Bearing 6203-2RS	60	174025	Bearing bed set	
24	174010	Body	[1][3]201	177446	Operating instruction	
25	174005	Brush holder cover	[2][4]201	176244	Operating instruction	
26	174004	Diffuser	202	174349	Tool case	
27	176451	Stator set	204	179862	Grease 4 - 1,00 kg.	
28	174040	Armature set				
29	190020	Brush holder set				
30	153014	Brush				
31	153015	Brush with a switch				

Note:

[1] - only for M 2000/AVR; [2] - only for M 2000; [3] - only for MA 2000/AVR; [4] - only for MA 2000

M 2000/AVR
M 2000
MA 2000/AVR
MA 2000

