

PROFESSIONAL

MB 2001V - 170167; MBA 2001V - 170307; MB 2001PV - 170865; MBA 2001PV - 170171

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description		
1	151649	Body	34	151611	Bearing bed		
2	151650	Brush holder cover	35	124720	Circlip A40		
3	151651	Diffuser	35****	330473	Circlip A40-1D		
4	152806	Stator set	36	117503	Spacer washer		
5	151679	Armature set	37	117504	Spacer washer		
6	152160	Fan	38	117505	Spacer washer		
7	151648	Protective washer	[1];[3]	39	117506	Gear set	
8	330308	Bearing 6082ZP63LDS18	[2];[4]	39	117509	Gear set	
9	151644	Brush holder set	40	113540	Oil - churning bush		
9****	190020	Brush holder set	41	113256	Nut		
10	151681	Brush	42	151615	Bush		
10*	153014	Brush	42**	154663	Bush		
11	151682	Brush with a switch	43	117277	Spring		
11*	153015	Brush with a switch	44	151613	Lock button		
12	164934	Rubber bush	45	330342	O-ring 6X2B		
13	360646	Screw 4x9.5	46	330352	O-ring 80X2B		
14	152537	Screw 3,9X74	47	360246	Screw M5x16		
15	360647	Screw 4x13	48	360677	Screw K5x25(D10)		
16	151656	Casing handle set	49	120724	Cord protector		
17	170660	Switch PS 16 E00	[1];[3]	50	152574	Cord with a plug	
18	151655	Lock button	[2];[4]	50	122051	Cord with a plug	
19	151654	Lock lever	51	151658	Rubber pad		
20	151413	Spring	52	121837	Back up disc washer		
21	360654	Screw 4x18	53	121838	Locking nut		
[1];[2]	22	152959	Electronic block	54	154269	Special spanner 240	
[3];[4]	22	152957	Electronic block	[1];[3]	55	151276	Disk guard 180E
23	151671	Cord clamp	[2];[4]	55	151268	Disk guard 230E	
24	360646	Screw 4x9.5	56	121265	Handle		
25	151657	Gear box set	57	152513	Plate		
26	330125	Bearing HK 1212	57****	113244	Spiral spring		
27	330943	Bearing 6202 2RSL P63 LDS18SpA	201	170497	Operating instruction		
27***	330943	Bearing 6202 2RSL P63 LDS18SpA	202	170377	Packaging		
28	330126	Dust protector/NILOS-ring 6202	204	179870	Grease 6 - 1,00 kg.		
29	117268	Spring washer					
30	330472	Circlip A35					
30****	330732	Circlip A35-1D					
31	117269	Spindle					
32	152125	Bearing bed					
33	330124	Bearing 6203-2RS					

Note:

*- from 01.10.2004; **-from 08.08.2006; ***-from 01.02.2007; ****-from 01.02.2008; *****-from 01.02.2009

[1] - only for MB 2001V; [2] - only for MBA 2001V; [3] - only for MB 2001PV; [4] - only for MBA 2001PV

**MB 2001V
MBA 2001V
MB 2001PV
MBA 2001PV**

