

MB 2002 (from 01.08.2001) - 164919; MBA 2002 (from 01.08.2001) - 163305

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
	1	151609 Gear box set		33	127546 Capacitor
	2	330125 Bearing HK 1212		34	114601 Spacer washer
	3	330293 Bearing 6202ZTNHP63LDS18		35	116759 Fan
	4	330126 Dust protector/NILOS-ring 6202		36	113614 Protective washer
	5	117268 Spring washer		37	330291 Bearing 60002ZP63LDS18
	6	330732 Circlip A35-1D		38	124211 Casing handle set
	7	117269 Spindle	[1]	39	163468 Switch
	8	330124 Bearing 6203-2RS	[2]	39	151166 Switch
	9	151611 Bearing bed		40	256500 Cord clamp
	10	330473 Circlip A40-1D		41	360646 Screw 4x9.5
	11	117503 Spacer washer		42	360648 Screw 4x16
	12	117504 Spacer washer		43	116757 Rubber bush
	13	117505 Spacer washer		44	116756 Rubber pad
[1]	14	117506 Gear set	[1]	45	117412 Outlet
[2]	14	117509 Gear set	[2]	45	117411 Outlet
	15	113540 Oil - churning bush		46	117412 Outlet
	16	113256 Nut		47	125846 Electronic block
	17	154663 Bush		48	360677 Screw K5x25(D10)
	18	117277 Spring		49	119263 Screw KB 40x45/25
	19	151613 Lock button		50	122051 Cord with a plug
	20	330342 O-ring 6X2B		51	120724 Cord protector
	21	330352 O-ring 80X2B		52	124212 Brush holder cover
	22	360246 Screw M5x16		53	360646 Screw 4x9.5
	24	124210 Body		54	121837 Back up disc washer
	25	116751 Diffuser		55	121838 Locking nut
	26	112052 Screw 3,9X74		56	154269 Special spanner 240
	27	124060 Stator set	[1]	57	151736 Disk guard 180
	28	122494 Armature set	[2]	57	151739 Disk guard 230
	29	116752 Brush holder set		58	121265 Handle
	30	125904 Brush with a switch			
	31	125905 Brush			
	32	131952 Rubber bush			

Note:
 [1] - only for MB 2002 from 01.08.2001;
 [2] - only for MBA 2002 from 01.08.2001

**MB 2002 (from 01.08.2001)
 MBA 2002 (from 01.08.2001)**

