

MBA 2002S (from 01.08.2001) - 163307

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
1	151609	Gear box set	32	131952	Rubber bush
2	330125	Bearing HK 1212	33	127546	Capacitor
3	330293	Bearing 6202ZTNHP63LDS18	34	114601	Spacer washer
4	330126	Dust protector/NILOS-ring 6202	35	116759	Fan
5	117268	Spring washer	36	113614	Protective washer
6	330732	Circlip A35-1D	37	330291	Bearing 60002ZP63LDS18
7	117269	Spindle	38	129859	Casing handle set
8	330124	Bearing 6203-2RS	39	163468	Switch
9	151611	Bearing bed	40	256500	Cord clamp
10	330473	Circlip A40-1D	41	360646	Screw 4x9.5
11	117503	Spacer washer	42	360648	Screw 4x16
12	117504	Spacer washer	43	116757	Rubber bush
13	117505	Spacer washer	44	116756	Rubber pad
14	117509	Gear set	45	117411	Outlet
15	113540	Oil - churning bush	46	117412	Outlet
16	113256	Nut	47	125846	Electronic block
17	154663	Bush	48	360318	Screw A-K 5x25
18	117277	Spring	49	119263	Screw KB 40x45/25
19	151613	Lock button	50	122051	Cord with a plug
20	330342	O-ring 6X2B	51	120724	Cord protector
21	330352	O-ring 80X2B	52	124212	Brush holder cover
22	360246	Screw M5x16	53	360646	Screw 4x9.5
24	124210	Body	54	121837	Back up disc washer
25	116751	Diffuser	55	121838	Locking nut
26	112052	Screw 3,9X74	56	154269	Special spanner 240
27	124060	Stator set	57	151739	Disk guard 230
28	122494	Armature set	58	121265	Handle
29	116752	Brush holder set			
30	125904	Brush with a switch			
31	125905	Brush			

MBA 2002S (from 01.08.2001)

