

PROFESSIONAL

MB 2200P - 177373; MB 2200 - 177371; MBA 2200P - 177374; MBA 2200 - 177372

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description	
1	174013	Gear box	33	360646	Screw 4x9.5	
2	330125	Bearing HK 1212	34	360870	Screw 3.9X60	
3	330944	Bearing 6300 2RSL P63 LDS18SpA	35	154350	Fan	
4	153341	Gasket	36	151648	Protective washer	
5	173936	Inner Flange	37	331149	Bearing 608-2RS-P63 LDS18SpA	
6	173934	Circlip	38	174002	Handle	
7	174022	Spindle	[1][3]	39	170669	Switch PS16E02
8	173935	Rubber bush	[2][4]	39	170668	Switch PS16E01
9	174012	Bearing bed	40	360654	Screw 4x18	
10	117504	Spacer washer	41	151671	Cord clamp	
11	117505	Spacer washer	42	360646	Screw 4x9.5	
[1][2]	12	152668	Gear set	43	361120	Screw K5X40(D10)
[3][4]	12	152666	Gear set	44	120724	Cord protector
13	113256	Nut	45	152574	Cord with a plug	
14	174007	Bush	46	360255	Screw A-K 5x30	
15	174021	Spring	47	121837	Back up disc washer	
16	174008	Pin	48	121838	Locking nut	
17	330344	O-ring 6X1.5B NBR70	[1][2]	49	151276	Disk guard 180E
18	330352	O-ring 80X2B	[3][4]	49	151268	Disk guard 230E
19	360246	Screw M5x16	50	154269	Special spanner 240	
20	174006	Button	51	121265	Handle	
21	174020	Protective washer	52	113244	Spiral spring	
22	330473	Circlip A40-1D	60	174025	Bearing bed set	
23	330124	Bearing 6203-2RS	201	177979	Operating instruction	
24	177333	Body	202	174349	Tool case	
25	174005	Brush holder cover	204	179862	Grease 4 - 1,00 kg.	
26	174004	Diffuser				
27	177406	Stator set				
28	177405	Armature set				
29	190020	Brush holder set				
30	153014	Brush				
31	153015	Brush with a switch				
32	164934	Rubber bush				

Note:

[1] - only for MB 2200P; [2] - only for MB 2200; [3] - only for MBA 2200P; [4] - only for MBA 2200

MB 2200P
MB 2200
MBA 2200P
MBA 2200

