

MB 2400P/AVR - 176310; MB 2400P - 176310; MBA 2400P/AVR - 176311; MBA 2400P - 176311

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description	
1	174013	Gear box	31	153015	Brush with a switch	
2	330125	Bearing HK 1212	32	164934	Rubber bush	
3	330944	Bearing 6300.2RSL P63 LDS18SpA	33	360646	Screw 4x9,5	
4	153341	Gasket	34	152537	Screw 3,9X74	
5	173936	Inner Flange	35	154350	Fan	
6	173934	Circlip	36	151648	Protective washer	
7	174022	Spindle	37	331149	Bearing 608-2RS-P63 LDS18SpA	
8	173935	Rubber bush	38	174002	Handle	
9	174012	Bearing bed	39	170669	Switch PS16E02	
10	117504	Spacer washer	40	360654	Screw 4x18	
11	117505	Spacer washer	41	151671	Cord clamp	
[1][2]	12	152668	Gear set	42	360646	Screw 4x9,5
[3][4]	12	152666	Gear set	43	361120	Screw K5X40(D10)
13	113256	Nut	44	120724	Cord protector	
14	174007	Bush	45	152574	Cord with a plug	
15	174021	Spring	46	360255	Screw A-K 5x30	
16	174008	Pin	47	121837	Back up disc washer	
17	330344	O-ring 6X1.5B NBR70	48	121838	Locking nut	
18	330352	O-ring 80X2B	[1][2]	49	151276	Disk guard 180E
19	360246	Screw M5x16	[3][4]	49	151268	Disk guard 230E
20	174006	Button	50	154269	Special spanner 240	
21	174020	Protective washer	[1][3]	51	173725	Handle AVR M14/L12
22	330473	Circlip A40-1D	[2][4]	51	121265	Handle
23	330124	Bearing 6203-2RS	52	113244	Spiral spring	
24	174000	Body	60	174025	Bearing bed set	
25	174005	Brush holder cover	[1][3]201	177446	Operating instruction	
26	174004	Diffuser	[2][4]201	176244	Operating instruction	
27	176330	Stator set	202	174349	Tool case	
28	175423	Armature set	204	179862	Grease 4 - 1,00 kg.	
29	190020	Brush holder set				
30	153014	Brush				

Note:
 [1] - only for MB 2400P/AVR; [2] - only for MB 2400P;
 [3] - only for MBA 2400P/AVR; [4] - only for MBA 2400P

MB 2400P/AVR
 MB 2400P
 MBA 2400P/AVR
 MBA 2400P

