

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
1	184508	Lock piece	45	184521	Wrench
2	184507	Spring	46	184526	Fender ring
3	184506	Frame	47	184525	Nut
4	184505	Laser holder	48	184524	Spring
5	184494	Safety cover	49	184522	Screw M5x8
6	184497	Screw M4x12	50	184523	Big mat picece
7	184485	Screw M4x14	51	184527	Depth bevel scale housing
8	184503	Laser	52	184546	Screw ST4x16
9	184509	Screw M4x20	53	184558	Screw M5x28
10	184486	Spring	54	184557	Left handle
11	184502	Screw M4	55	184552	Cable
12	184504	Locating circlip	56	184556	Laser switch and Tranformer
13	184501	Site block circular	57	184555	Laser knob
14	184500	Washer M5x14x1	58	184559	Washer
15	184499	Screw M5x18	59	184554	Switch
16	184510	Bearing HK101610	60	184553	Capacitance
17	184511	Cogwheel	61	184551	Screw ST4x14
18	184512	Gear	62	184550	Cable bat
19	184513	Check ring	63	184549	Cable jacket
20	184514	Bearing 6003	64	184548	Right Handle
21	184515	Front cover	65	184547	Screw M5
22	184516	Screw M5x10	66	184545	Back cover
23	184517	Screw ST 4.8x40	67	184544	Screw ST 4.2x12
24	184518	Plastic ring H9J100200	68	184543	Brush bat
25	184498	Anchorage	69	184540	Carbon brush
26	184497	Screw M4x12	70	184541	Insert piece
27	184496	Half circle key	71	184542	Brush cover
28	184495	Spindle	72	184539	Brush holder
29	184519	Spring	73	184537	Housing
30	184493	Washer	74	184536	Stator
31	184492	Inner plate	75	184535	Screw ST 4.2x72
32	184490	Outer plate	76	184534	Air baffle plate
33	184487	Head shell	77	184533	Bearing Sleeve
34	184484	Washer	78	184532	Bearing 609
35	184482	Pin	79	184531	Rotor
36	184481	Nut M6	80	184530	Bearing 6002
37	184479	Angle traveling	81	184489	Washer
38	184480	Washer	82	184488	Screw M8x16
39	184483	Screw M6x14	83	184491	Saw blade
40	184528	Screw M8x20	84	184478	Screw
41	184477	Check screw	85	184475	Parallel guide
42	184529	Screw	86	184560	Wrench
43	184476	Base plate			
44	184520	Wrench			

TK 85

