

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
----------	---------	-------------	----------	---------	-------------

- 1 181801 Chuck screw
- 2 181802 Chuck
- 3 181803 Torque setting ring
- 4 181804 Gear box one speed
- 5 181805 Motor cover
- 6 181806 Motor
- 7 181807 Interior wires
- 8 181808 Power indicator assembly
- 9 181809 Power indicator cover
- 10 181810 Switch
- 11 181811 Body power connector
- 12 181812 Light pcb /led/
- 13 181813 Light cover
- 14 181814 Left housing
- 15 181815 cap
- 16 181816 Right housing

- 17 181817 Steering block
- 18 181818 Torque spring
- 19 181819 Bit bracket
- 21 181821 Top of battery pack
- 22 181822 Top insulation
- 23 181823 Battery power connector
- 24 181824 Battery cell
- 25 181825 Bottom insulation
- 26 181826 Battery pack button
- 27 181827 Bottom spring
- 28 181828 Battery body
- 29 181829 Screws
- 30 181790 Battery set BR 9.6E
- 31 181791 Charger EU BR 9.6E
- 31 181792 Charger GB BR 9.6E
- 204 178796 Grease 10 - 1,00 kg.

BR 9,6E

