

PROFESSIONAL

BN 503 - 180058; BN 604 - 180059

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description	
1	182595	Gear box housing	39	182644	Cord sleeve	
2	182596	Needle Bearing HK 1212B	40	182646	Flat washer 5B	
3	182597	Excentric spindle	41	182645	Screw 5x12	
4	182598	Bearing 6303-ZE	42	182643	Plug	
5	182599	Right-screwing bevel gear Z2	43	182609	Auxiliary handle	
6	182604	Needle Bearing HK 0709B	44	182612	Flat washer 5B	
7	182603	Flat washer 7B	45	182611	Spring washer Φ 5	
8	182602	Left-screwing small gear Z3	46	182610	Bolt M5x15	
9	182613	Position sheth for gear box housing	47	182608	Position pin for piston set	
10	182615	Screw M4x12	48	182601	Needle Bearing HK 2020B	
11	182614	Bearing shield	49	182600	Connecting pole	
12	182616	Plastic sealing ring	50	182605	Handle	
13	182617	Ball bearing 609-2E	51	182606	Flat washer Φ 7B	
14	182618	Bevel gear(right) for output shaft Z4	52	182607	Bolt M12x25	
15	182619	Fan	[1]	53	182585	Piston pin
16	182620	Armature	[2]	53	182660	Piston pin
17	182621	Ball bearing 607-2E	[1]	54	182586	Piston
18	182622	Copper washer	[2]	54	182661	Piston
19	182623	Wind block cover	[1]	55	182587	Pole
20	182624	Stator	[2]	55	182662	Pole
21	182637	Switch button	[1]	56	182588	Piston set
22	182638	Switch bar	[2]	56	182663	Piston set
23	182639	Screw	[1]	57	182589	Copper washer
24	182640	Cord flange	[2]	57	182664	Copper washer
25	182641	Flat washer 4B	[1]	58	182590	Cutter
26	182625	Motor housing	[2]	58	182665	Cutter
27	182626	Screw	[1]	59	182593	Guide block for pole
28	182627	Brush Holder	[2]	59	182668	Guide block for pole
29	182629	Screw 3.7x15	[1]	60	182592	Down mould
30	182630	Flat washer 4B	[2]	60	182667	Down mould
31	182631	Cord flange	[1]	61	182594	Screw 4x12
32	182632	Switch	[2]	61	182669	Screw M5x14
33	182628	Carbon brush	[1]	62	182591	Big nut
34	182633	Capacitor	[2]	62	182666	Big nut
35	182634	Capacitor cover				
36	182635	Screw 3.7x15				
37	182636	Flat washer 4B				
38	182642	Motor back cover				

Note:
[1] - only for BN 503; [2] - only for BN 604

BN 503 BN 604

